



This is a **trusted**™ product

QUICK START GUIDE



Go to the Trusted Data Portal

Visit trustedglobal.com and click "Log in".
New users are sent login information
in an e-mail from Trusted A/S.



Set up transmission schedule

Navigate to your device and click "Edit" to
set up a transmission schedule
that fits your needs.



Edit device settings

Stay on "Edit" to set up the device to fit your tracking needs. Changes are sent to the device upon the next transmission.



Activate the hardware

Place a magnet on: "Activate with magnet" on the label and wait until it flashes red **continuously**.



All good to go

Your device is active and will transmit data according to its transmission schedule.

Note: It may take up to 15 minutes for new devices to stop blinking and appear online.

Scan for
more
guides



If you have any questions, please
contact your Trusted supplier.

Trusted A/S [trustedglobal.com](https://www.trustedglobal.com)